

All Garrett Wade Automatic Punches are used with hand pressure only.

Place the point on your mark and press down until you hear and feel a "click" which indicates a depression has been made in your work, ready to help guide your drill bit accurately.

The Self Centering Punch automatically centers the point when it is placed in a countersunk hole of a piece of hardware, such as hinges.

The Carpenters Punch specially made with an extra long pin to pass through the mounting holes of shelf standards or boards to make an accurate prick mark on walls. The spring is made at a lighter pressure so that a mark will be made in soft materials like wallboard, plaster and wood.

Garrett Wade Technical Department

For further assistance, call the Garrett Wade Technical Department at 800 221 2942, or email us at mail@garrettwade.com