




Premium Watering Nozzle Instructions



The brass knob pictured is a Flow Control Valve. Its purpose is to control the volume of water to the nozzle. The valve should only be operated with the trigger pulled and water flowing. If water is on but trigger not pulled, the water pressure will make rotating the valve difficult. The valve only rotates 90 degrees (quarter turn) as indicated by photo above. Do not use any tools to rotate the valve .. Using pliers to rotate the valve may damage the valve

If you need further assistance contact Garrett Wade Customer Service @ 800-221-2942 or mail@garrettwade.com